

Symbol Marks

The following symbols stand for:



:Apply engine oil.



:Apply brake fluid.



:Apply grease.



:Apply DEXRON® II Automatic Transmission Fluid.



: Apply Power Steering Fluid.



:Apply or check vacuum.

Abbreviation

2WS	Two Wheel Steering
4WS	Four Wheel Steering
A/C	Air Conditioner
ALB	Anti Lock Brake
A/T	Automatic Transmission
ATF	DEXRON® II Automatic Transmission Fluid
ECU	Electronic Control Unit for Fuel-Injection System
EGR	Exhaust Gas Recirculation
EACV	Electronic Air Control Valve
L.	Left Side
LHD	Left Hand Drive
M/T	Manual Transmission
PCV Valve	Positive Crankcase Ventilation Valve
P/S	Power Steering
R.	Right Side
RHD	Right Hand Drive
TDC	Top Dead Center