



Noise and Vibration

NOTE: Pump noise in first 2–3 minutes after starting in cold weather (– 20°C, – 4°F or colder) is normal.

