

Special Tools

Special Tools (Common with Other Models)

5. Engine

No.	Tool Number	Description	Q'ty	Remarks
①	07GAF-PH60100	Piston Base Head	1	
②	07GAF-PH60200	Pilot Collar	1	
③	07GAF-PH60300	Piston Pin Base Insert	1	
④	07GAF-PH70100	Pilot Collar	1	
⑤	07406-0030000	Oil Pressure Gauge Adaptor	1	
⑥	07743-0020000	Adjustable Valve Guide Driver	1	
⑦	07746-0010400	Attachment 52 x 55 mm	1	
⑧	07749-0010000	Driver	1	
⑨	07757-PJ10100	Valve Spring Compressor Attachment	1	
⑩	07757-0010000	Valve Spring Compressor	1	
⑪	07924-PD20003	Ring Gear Holder	1	
⑫	07942-SA50000 or 07942-8230000	Valve Guide Driver, 7.0 mm	1	
⑬	07942-6570100 or 07942-6110000	Valve Guide Driver, 6.6 mm	1	
⑭	07943-6890100	Valve Guide Driver Attachment	1	
⑮	07947-SB00100	Seal Driver	1	
⑯	07948-SB00101	Driver Attachment	1	
⑰	07973-PE00302 or 07973-PE00301	Adj. Piston Pin Driver	1	
⑱	07973-6570002	Piston Pin Dis/Assembly Tool Set	1	
⑱-1	07973-6570500	Piston Base	(1)	Component Tool
⑱-2	07973-6570600	Piston Base Spring	(1)	
⑲	07984-SA50000 or 07984-6890101	Valve Guide Reamer, 7.0 mm	1	
⑳	07984-6110000 or 07984-6570101	Valve Guide Reamer, 6.6 mm	1	

6. Fuel and Emissions

No.	Tool Number	Description	Q'ty	Remarks
①	07GMJ-ML80100	Inspection Adaptor	1	
②	07HAZ-PJ70000	ECU Check Adaptor A	1	<Carbureted Engine>
③	07HAZ-PJ70100	ECU Check Adaptor B	1	<Carbureted Engine>
④	07401-0010000	Float Level Gauge	1	<Carbureted Engine>
⑤	07406-0040001	Fuel Pressure Gauge	1	<Fuel-Injected Engine>
⑥	07411-0020000	Digital Circuit Tester	1	
⑦	07614-0050100	Fuel Line Clamp	1	<Carbureted Engine>
⑧	07999-PD6000A	System Checker Harness	1	<Fuel-Injected Engine>

7. Clutch

No.	Tool Number	Description	Q'ty	Remarks
①	07GAG-PF50100	Clutch Disc Alignment Tool	1	
②	07924-PD20003 or 07924-PD20002	Ring Gear Holder	1	



8. Manual Transmission

No.	Tool Number	Description	Q'ty	Remarks
①	07GAD—PG40100	Oil Seal Driver	1	
②	07GAJ—PG20101	Mainshaft Thrust Clearance Inspection Tool	1	
③	07936—6340000	Bearing Puller Set	1	
④	07936—6890101	Bearing Remover Attachment	1	
⑤	07746—0010300	Attachment, 42 x 47 mm	1	
⑥	07746—0010400	Attachment, 52 x 55 mm	1	
⑦	07746—0010500	Attachment, 62 x 68 mm	1	
⑧	07749—0010000	Driver	1	
⑨	07947—SD90100 or 07GAD—PG40100	Oil Seal Driver	1	
⑩	07947—6110500	Oil Seal Driver	1	
⑪	07GAJ—PG20201	Preload Inspection Tool	1	
⑫	07746—0030100	Driver	1	
⑬	07947—SD90100 or 07GAD—PG40100	Oil Seal Driver	1	
⑭	07947—6110500	Oil Seal Driver	1	

9. Automatic Transmission

No.	Tool Number	Description	Q'ty	Remarks
①	07GMJ—ML80100	Inspection Adaptor Tool	1	
②	07GAB—PF50100	Mainshaft Holder	1	
③	07GAE—PG40001	Clutch Spring Compressor Set	1	
③-1	07GAE—PG40200	Clutch Spring Compressor Bolt Assembly	(1)	Component Tool
③-2	07HAE—PL50100	Clutch Spring Compressor Attachment	(1)	
③-3	07960—6120100	Clutch Spring Compressor Attachment	(1)	
④	07HAC—PK40100 or 07GAC—PG40100 07GAC—PG40101 07GAC—PG40102	Housing Puller	1	
⑤	07HAF—PK40100	Gear Installer	1	
⑥	07406—0020003 or 07406—0020201	Oil Pressure Gauge Set	1	
⑦	07936—6340000	Bearing Puller Set	1	
⑧	07GAC—PF40210	Bearing Remover Attachment	1	
⑨	07746—0010500	Attachment, 62 x 68 mm	1	
⑩	07749—0010000	Driver	1	
⑪	07947—6340201	Driver Attachment E	1	
⑫	07947—6340500	Bearing Driver Attachment E	1	
⑬	07GAJ—PG20201	Preload Inspection Tool	1	
⑭	07746—0030100	Driver	1	
⑮	07947—SD90100 or 07GAD—PG40100	Oil Seal Driver	1	
⑯	07947—6110500	Oil Seal Driver	1	

Special Tools

Special Tools (Common with Other Models)

10. Driveshaft				
No.	Tool Number	Description	Q'ty	Remarks
①	07GAD-SE00100	Oil Seal Driver	1	
②	07746-0010400	Attachment, 52 x 55 mm	1	
③	07746-0010500	Attachment, 62 x 68 mm	1	
④	07746-0040900	Pilot, 40 mm	1	
⑤	07749-0010000	Driver	1	
⑥	07947-SD90200	Oil Seal Driver	1	
⑦	07965-SD90100	Support Base	1	
⑧	07965-SD90200	Support Collar	1	

11. Power Steering (2WS/4WS Community)				
No.	Tool Number	Description	Q'ty	Remarks
①	07GAG-SD40000	P/S Tool Kit	1	
①-1	07GAG-SD40100	Piston Seal Ring Guide	(1)	— Component Tool
①-2	07GAG-SD40200	Piston Seal Sizing Tool	(1)	
①-3	07GAG-SD40300	Cylinder End Seal Slider	(1)	
①-4	07GAG-SD40400	End Seal Guide	(1)	
①-5	07GAG-SD40600	Tool Box	(1)	
②	07GAK-SE00100	P/S Pressure Gauge Adaptor Set	1	
②-1	07GAK-SE00110	P/S Joint Adaptor (Pump)	(1)	
②-2	07GAK-SE00120	P/S Joint Adaptor (Hose)	(1)	
③	07406-0010200	P/S Pressure Gauge Set	1	
③-1	07406-0010300	Pressure Control Valve	(1)	— Component Tool
③-2	07406-0010400	Pressure Gauge	(1)	
④	07406-0010101	Bypass Tube Joint	1	
⑤	07746-0010300	Attachment, 42 x 47 mm	1	
⑥	07749-0010000	Driver	1	
⑦	07916-SA50001	40 mm Lock Nut Wrench	1	
⑧	07941-6920003	Ball Joint Remover	1	
⑨	07947-6340300	Driver Attachment	1	
⑩	07953-7190000	Collar Driver	1	
⑪	07974-SA50600	Pinion Seal Guide	1	



11. Power Steering (4WS Only)

No.	Tool Number	Description	Q'ty	Remarks
①	07HAA-SF10100	Lock Nut Socket 36 x 41 mm	1	Component Tool
②	07HAG-SF10000	4WS Tool Kit	1	
②-1	07HAG-SF10100	Piston Seal Ring Guide	(1)	
②-2	07HAG-SF10200	Piston Seal Ring Sizing Tool	(1)	
②-3	07HAG-SF10300	Pinion Seal Ring Guide	(1)	
②-4	07HAG-SF10400	Pinion Seal Sizing Tool	(1)	
②-5	07HAG-SF10500	Driver Seal Ring Guide	(1)	
②-6	07HAG-SF10600	Tool Box	(1)	
③	07HAJ-SF10100	Rack Adjuster Gauge Holder Set	1	
④	07HAJ-SF10201	Rear Steering Center Lock Pin	1	
⑤	07HAJ-SF10300	Stroke Rod Holder Set	1	
⑥	07HFJ-SF10400	Inspection Adaptor	1	
⑦	07703-0010101	Torx Bit Driver T40	1	
⑧	07746-0010700	Attachment 24 x 26 mm	1	

12. Suspension

No.	Tool Number	Description	Q'ty	Remarks
①	07HAF-SF10200	Bearing Supporting Attachment	1	
②	07GAE-SE00101 or 07GAE-SE00100	Spring Compressor	1	
③	07GAF-SE00100	Hub Assembly Pin	1	
④	07GAF-SE00200	Front Assembly Driver Attachment	1	
⑤	07GAF-SE00401	Front Hub Base	1	
⑥	07GAF-SD40700	Hub Dis/Assembly Base	2	
⑦	07GAG-SD40700	Ball Joint Boot Clip Installation Guide	1	
⑧	07HAD-SF10100	Hub Bearing Driver	1	
⑨	07GAK-0010100	Wheel Alignment Gauge Attachment	1	
⑩	07HAF-SF10100	Ball Joint Dis/Assembly Tool Kit	1	
⑩-1	07HAF-SF10110	Ball Joint Remover Base	1	
⑩-2	07HAF-SF10120	Ball Joint Installer Base	1	
⑩-3	07HAF-SF10130	Ball Joint Remover/Installer	1	
⑪	07HAJ-SF10201	Rear Steering Center Lock Pin	1	
⑫	07HGJ-0010000	Toe Inspection Gauge Set	1	
⑬	07703-0010100	Torx T40 Bit	1	
⑭	07746-0010400	Attachment, 52 x 55 mm	1	
⑮	07746-0010500	Attachment, 62 x 68 mm	1	
⑯	07749-0010000	Driver	1	
⑰	07941-6920003	Ball Joint Remover	1	
⑱	07965-SB00000	Ball Joint Dis/Assembly Tool Set	1	
⑱-1	07965-SB00100	Ball Joint Remover Base	1	
⑱-2	07965-SB00200	Ball Joint Installer Base	1	
⑱-3	07965-SB00300	Ball Joint Remover/Installer	1	
⑲	07965-SD90100	Supporting Base	1	
⑳	07965-6920201	Front Hub Dis/Assembly Tool, B	1	
㉑	07974-SA50700	Ball Joint Boot Clip Installation Guide	1	
㉒	07974-SA50800	Ball Joint Boot Clip Installation Guide	1	

Special Tools

Special Tools (Common with Other Models)

13. Brakes (Conventional Brakes Community)

No.	Tool Number	Description	Q'ty	Remarks
①	07921-0010001	Flare Nut Wrench	1	
②	07510-6340300	Vacuum Joint Tube A	1	
③	07404-5790300	Vacuum Gauge	1	
④	07410-5790500	Tube Joint Adaptor	1	
⑤	07406-5790200	Pressure Gauges	2	
⑥	07410-5790100	Pressure Gauge Attachment	2	
⑦	07510-6340100	Pressure Gauge Joint Pipe	2	
⑧	07749-0010000	Driver	1	
⑨	07947-6890300	Driver Attachment, C	1	
⑩	07GAG-SE00100	Rod Bolt Adjustment Gauge	1	
⑪	07HAE-SG00100	Brake Spring Compressor	1	
⑫	07914-SA50000	Snap Ring Pliers	1	

13. Brakes (ALB Only)

No.	Tool Number	Description	Q'ty	Remarks
①	07508-SB00000	ALB Checker	1	
②	07HAJ-SG00300	ALB Checker Adaptor	1	
③	07907-SB00000	ALB T-Wrench	1	
④	07921-0010001	Flair Nut Wrench	1	
⑤	07965-5790300	Cup Guide	1	
⑥	07510-6340300	Vacuum Joint Tube A	1	
⑦	07404-5790300	Vacuum Gauge	1	
⑧	07410-5790500	Vacuum Tube Joint Adaptor	1	
⑨	07406-5790200	Pressure Gauges	2	
⑩	07410-5790100	Pressure Gauge Attachments	2	
⑪	07510-6340100	Pressure Gauge Joint Pipe	1	
⑫	07HAK-SG00110	Pressure Gauge Joint Pipe	1	

14. Body

No.	Tool Number	Description	Q'ty	Remarks
①	07GAZ-SE30100	Torsion Rod Assembly Tool	1	

15. Heater and Air Conditioner

No.	Tool Number	Description	Q'ty	Remarks
①	07HAF-SF10300	Seal Seat Remover	1	
②	07HAF-SF10400	Seal Remover/Installer	1	

16. Electrical

No.	Tool Number	Description	Q'ty	Remarks
①	07GAC-SE00200	Fuel Sender Wrench	1	