


System Description

Electrical Connections

[KX, KS, KZ model]



- ① CRANKING LEAK SOLENOID VALVE
- ② AIR SUCTION CONTROL SOLENOID VALVE
- ③ VACUUM PISTON CONTROL SOLENOID VALVE
- ④ PURGE CUT-OFF SOLENOID VALVE
- ⑤ PRIMARY SLOW MIXTURE CUT-OFF SOLENOID VALVE (LEFT)
- ⑥ PRIMARY SLOW MIXTURE CUT-OFF SOLENOID VALVE (RIGHT)
- ⑦ A/C IDLE BOOST SOLENOID VALVE
- ⑧ INNER VENT SOLENOID VALVE
- ⑨ AIR LEAK SOLENOID VALVE
- ⑩ AIR VENT CUT-OFF SOLENOID VALVE



[Except KX, KS, KZ model]

